










# OIL PUMP COMPONENTS



**N\*m (kgf\*cm, ft\*lbf)** : Specified torque


LU




**N\*m (kgf\*cm, ft\*lbf)** : Specified torque


● Non-reusable part

LU





LU




**N\*m (kgf\*cm, ft\*lbf)** : Specified torque

● Non-reusable part

➡ Apply MP grease

LU



LU

**N\*m (kgf\*cm, ft\*lbf)** : Specified torque

● Non-reusable part